## **COMPENSATION PROFILES**

These are wooden slats  $1000 \text{ mm } \times 20 \text{ mm}$  used to compensate for the extra width created when joining two single frames to form a double frame using the separate joining kit.

Easy to install, they are positioned on the frame in between the jambs and the frame effectively extending the jams the extra distance required. See below.

The advantage of using these profiles is that you can still use the standard sized doors used in the single frames.



